

SW10™ SHUTTER SWITCH



USER MANUAL 3

GEBRAUCHSANLEITUNG 7

GUIDE UTILISATEUR 11

MODO DE EMPLEO 15

MANUALE D'ISTRUZIONI 19

GEBRUIKSAANWIJZING 23

USER MANUAL SW10 SHUTTER SWITCH

SAFETY WARNINGS

- The wiring of your electrical installation is live (230 V) and extremely dangerous. Never connect the module when plugged into the mains. Always turn off the main switch before starting the installation.
- This product is for professional use and should be installed by a certified installer.
- To prevent short circuits, this product should only be used inside and only in dry spaces. Do not expose the components to rain or moisture. Do not use the product close to a bath, swimming pool etc.
- Do not expose the components of your systems to extremely high temperatures or bright light sources.
- Do not open the product: the device contains live parts. The product should only be repaired or serviced by a qualified repairman.
- In case of improper usage or if you have opened, altered and repaired the product yourself, all guarantees expire. Marmitek does not accept responsibility in the case of improper usage of the product or when the product is used for purposes other than specified. Marmitek does not accept responsibility for additional damage other than covered by the legal product responsibility.
- Automatic switching devices provide comfort, but can also be dangerous. They can surprise people or can ignite clothing hanging over an electric heat source. Please be careful and take appropriate measures to avoid accidents.

How does Marmitek X-10 work?

Marmitek X-10 components use the existing mains wiring to communicate (using Marmitek X-10 signals). You can build a complete system using the three different kind of components of the Marmitek X-10 System:

- 1. Modules:** These components will receive Marmitek X-10 signals and will switch or dim the attached lamp or appliance.
- 2. Controllers:** These components will transmit Marmitek X-10 signals and thus will control the Modules.
- 3. Transmitters:** Wireless components like remotes. The signals of these components will be received by a controller with transceiver functionality (IRRF 7243, TM13 or console of a Marmitek Security System). The Transceiver will translate the signals into Marmitek X-10 signals on the power line.

Addresses

You can select up to 256 addresses by setting two code wheels on the modules. The two code wheels are dividing the address into a House Code (A .. P) and a Unit Code (1 .. 16). On Controllers the House Code is also selectable. When Modules and Controllers are set to the same House Code they will work together.

The Marmitek X-10 System contains many standardized commands whereby modules set to the same House Code will respond simultaneously (e.g. All lights on, all off).

Signal Range

Range of Marmitek X-10 signals over the Power Line and how to increase the range.
The Marmitek X-10 System is based on power line communication. The range of the

Marmitek X-10 signals very much depends on the local circumstances. On average the range is a cable length of 80 meters.

If you have difficulties with the range of your Marmitek X-10 signals, please pay attention to the following facts:

1. When more than one phase is used for your electrical system, it is necessary to couple these phases for the Marmitek X-10 signals. For coupling you can use FD10 Phase Couplers/Filters. You only need to install a Phase Coupler/Filter when your wall outlets and light switches are divided over more than one phase (more than one group is no problem). For bigger buildings or longer distances we advice you to use an active repeater instead of passive FD10's.

2. It is possible that Marmitek X-10 signals are attenuated by devices and lights which are connected to the power line. In a normal home situation this effect is negligible (the Marmitek X-10 system is using active gain control to eliminate the effects). However, it is possible that a particular device in your house is attenuating the signals so much that the range of Marmitek X-10 signals is decreased significantly. When you have range problems, it is wise to try to locate the device which is attenuating the signals simply by unplugging devices from the power line, and testing the differences in range for your Marmitek system. When e.g. your conclusion is that e.g. your computer monitor is attenuating the signal, you can use a FM10 Plug-in Filter between the power line and the monitor to eliminate the effects.

Known devices which can cause attenuation are:

PC Monitors
PC's with heavy internal power supplies
Old Televisions
Copiers
Fluorescent Lights
Gas Discharge Lamps (Energy Saving Lamps)

3. Some (old) devices are able to disturb the signal by transmitting noise on the power line. Because the Marmitek X-10 signals are transmitted on 120 kHz, only noise on or near this frequency will have influence on the range. When you use a FM10 Filter to connect this device to the power line, the noise will be filtered.

4. The Marmitek X-10 protocol has several mechanism to avoid modules to be switched on or off by other sources than your Marmitek X-10 Controllers. However, it is possible that the Marmitek X-10 signals are disturbed by e.g. baby phones which are in TALK mode (continuous transmission). When these kind of signals are present on the power line it is possible that the Marmitek X-10 signals will not come through.

5. The mains do not stop at the front door of your home. Everything that is attached to mains nearby your home can have influence on Marmitek X-10 signals (e.g. heavy machinery). If you think that your system is influenced by devices out of your house, it is advisable to install FD10 Phase Coupler/Filter on each phase entering the house. These filters will block signals coming into or going out of your house, but will also match the impedance for the mains. The FD10's will not only filter but will also couple the phases (please see 1).

FAQ

What is the reason for modules to switch on/off spontaneously?

It is possible that a Marmitek X-10 System is installed at one of your neighbours using the same House Code. To solve this problem try to change the House Code of your system, or have FD10 Phase Coupler/Filter installed at your incoming mains.

My modules will not respond to my controller.

Make sure that the House Code on all Modules and Controllers are set to the same House Code (A .. P).

My modules will not react to my remote / sensor.

When you use a remote or sensor, you should have at least one TM13 Transceiver or Marmitek Security Console installed in your house. These components will translate the radio signals to the Marmitek X-10 signal on the power line. Only one Transceiver should be installed for all remotes and sensors set to the same House Code.

Am I able to increase the range of my remotes by using more Transceivers?

Yes, you can use more than one TM13 Transceiver in your home when the range of your remotes is not sufficient. The TM13 is using so called collision detection to prevent signals to be disturbed when more than one TM13 is transmitting. TM13's will wait for a quite power line before transmitting their data. To prevent your Marmitek X-10 System to become slow or to prevent dimming from becoming less smooth, make sure that the TM13 units are placed as far away from each other as possible.

USER INSTRUCTIONS SW10 SHUTTER SWITCH

SWITCH OFF APPROPRIATE MAINS FUSE BEFORE INSTALLING!

(INSTALLATION BY A CERTIFIED INSTALLER)

1. Take of the switch cover, remove both screws and take off the mounting plate.
2. Mount the mounting plate onto the flush mounting box with countersunk screws.
Position the plastic décor frame.
3. Connect cables:
Phase to L ()
Neutral to N
UP to UP
Down to DN
4. When connected, position Shutter Switch on the mounting plate and reinsert both screws.
5. Now program the switch using the following procedure:


PROGRAMMING THE SW10

Now the control electronics has to be calibrated in order to adjust to the time the shutter motor need from fully closed to fully open:

1. Switch on mains fuse.
2. Use the switch to drive the shutter all the way up.
3. With the aid of a screwdriver, adjust the House Code dial to the * position.
4. Now press the lower push button until the shutter is closed completely.
5. Release the button as soon as the shutter is closed. The electronics measure the elapsed time and stores it internally so that the switch always knows the position of the shutter.
6. Set the rotary code switches on the front side to the desired address
7. Put the switch cover back on.

The calibration is now completed. The internal electronics have measured and stored the time for raising and lowering the shutter. These values will not be lost even in case of mains failure. You are now able to control the switch both by hand and with a Marmitek X-10 Controller (the switch will not respond to Marmitek X-10 signals when the programming has not been executed).

The switch will respond to the following commands: ON: fully open, OFF: fully closed, DIM : 4 % up, BRIGHT: 4 % down.



Technical data

| | |
|-------------------------------|---|
| Supply voltage: | 230V +10% -15% 50 Hz |
| Supply current : | < 5.5 mA capacitive |
| Max. load: | 1400W/230V for motors |
| Signal sensitivity: | 15 mVpp min 50 mVpp max at 120 kHz |
| Input impedance: | > 180 Ohm (L - N) at 120 kHz |
| Connection: | Connecting clamps for phase, neutral, motor up and motor down |
| Ambient temperature: | - 10° C to + 50° C (operation) - 20° C to + 70° C (storage) |
| Dimensions: | 70x70x54mm |
| Overall mechanism dimensions: | Ø 48x31mm |



Environmental Information for Customers in the European Union

European Directive 2002/96/EC requires that the equipment bearing this symbol on the product and/or its packaging must not be disposed of with unsorted municipal waste. The symbol indicates that this product should be disposed of separately from regular household waste streams. It is your responsibility to dispose of this and other electric and electronic equipment via designated collection facilities appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. For more detailed information about the disposal of your old equipment, please contact your local authorities, waste disposal service, or the shop where you purchased the product.